



Frequently Asked Questions

[Show Part Numbers](#)

Q: How do I use the Function (Fn) and System keys on the this notebook?

A: To use a system key to perform a specific function, press and hold down the Fn key, press the system key with the desired image on it, and then release both keys.

Press and hold the FN key, then press this system key...	to...
F1	turn the status lights on or off.
F2	turn the optional wireless network on or off. Warning: Radio frequency wireless communication can interfere with equipment on commercial aircraft. Current aviation regulations require wireless devices to be turned off while traveling in an airplane. 802.11G (also known as wireless Ethernet or Wifi) communication devices are examples of devices that provide wireless communication. Important: Your notebook came to you with the optional wireless network turned off.
F3	to enter Standby mode. Press the power button to leave Standby mode.
F4	toggle the display in the following order: <ul style="list-style-type: none"> ■ Notebook display (default) ■ External monitor (if connected) ■ Both the notebook display and the external monitor (if an external monitor is connected)
F5	display the power status box in the upper-left corner of the screen. The menu shows the battery charge level, the BIOS version, and whether the AC power adapter is being used. Press the key combination again to close this box.
F8	increase the LCD brightness to full bright.
F9	play or pause a CD or DVD.
F10	stop a CD or DVD.
F11	play the previous track a CD or DVD.
F12	play the next track of a CD or DVD.
Up Arrow	increase the display brightness.
Down Arrow	decrease the display brightness.
Home	mute the sound.
PgUp	increase volume.
PgDn	decrease volume.
Scroll	to activate the numeric keypad. Press the same keys again to turn off the numeric keypad.

Gateway products are available through select retailers.

[Site Map](#) | [About Us](#) | [Contact Us](#) | [Feedback](#)

© 2013 All rights reserved. | [Legal](#) | [Privacy](#)

 [United States](#) (change country or region)